ANZO USA 121139 Installation Instructions

121139

Part number: 121139

trailfortress.com/anzo-usa-crystal-headlight-set-121139

Scan for fitment, price and install help

www.anzousa.com

5150 Eucalyptus Ave Unit A
Chino, Ca. 91710
888.360.3696

Read complete instructions before installation! Improper installation may void warranty

Description: Crystal Headlight
Part Number: 121139 - 121132
Application: 97-00 Toyota Tacoma



Tools Needed
Phillips Screwdriver , 10mm Socket and ratchet.



Remove the bolts from the top of the grille and the two phillips screws located at the bottom corners.



Remove the 10mm bolt from the top inner part of the light.



Remove the phillips screw holding the parking lamp in.



Pull the parking lamp straight out.



Remove the two 10mm nuts located behind the parking lamp.



Remove the 10mm bolt located on the bottom of the light.



Pull the headlight straight out and unplug the harness from the back.



Install your new light by reversing these instructions. Check all funtions of the light before operating on the highway.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

© 2008 AnzoUSA™. All rights reserved.