ANZO USA 211048 Installation Instructions

211048

Part number: 211048

trailfortress.com/anzo-usa-tail-light-assembly-211048

Scan for fitment, price and install help

www.anzousa.com
5150 Eucalyptus Avenue Unit A
Chino, Ca. 91710
888.360.3696

Read complete instructions before installation! Improper installation may void warranty

Description: Tail Light
Part Number: 211046-211048-211170-211171
Application: 1994-2001 Dodge Ram



Tools needed: T27 torque screw.



Step 1: Locate the two t27 screws and remove them.



Step 2: Take off the tail light from the vehicle.



Step 3: Twist off the light bulbs from the tail light.



Step 4: Twist in the bulbs into the new Anzo tail light.



Step 5: Reinstall the tail lights onto the vehicle.



Step 6: Test all functions before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

© 2008 AnzoUSA™. All rights reserved.