TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

ANZO USA 511048 Installation Instructions

511048

Part number: 511048

trailfortress.com/anzo-usa-parking-light-assembly-511048

Scan for fitment, price and install help

14885 Monte Vista Avenue
Chino, Ca. 91710
888.360.3696
www.anzousa.com

Read complete instructions before installation! Improper installation may void warranty

Description: Parking light
Part Number: 511048-511050
Application: 1988-1998 Chevy Fullsize Truck







Tools needed: Phillips screwdriver.

Step 1: Remove the four phillips screw to remove the parking lights.



Step 2: Remove the parking lights from the vehicle.



Step 3: Twist off the parking light bulb sockets.



Step 4: Twist off the bulb from the socket.



Step 5: Twist the new Anzo parking light bulb connector to the socket.



Step 6: Replace the four phillips screw.



Step 7: Test all functions before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

© 2008 AnzoUSA™. All rights reserved.