TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

ANZO USA 531029 Installation Instructions

Third Brake Light Assembly for Chevrolet Silverado

Part number: 531029

trailfortress.com/third-brake-light-assembly-chevrolet-silverado-anzo-usa-531029

Scan for fitment, price and install help

14885 Monte Vista Avenue
Chino, Ca. 91710
888.360.3696
www.anzousa.com

Read complete instructions before installation! Improper installation may void warranty

Description: 3rd Brake Light
Part Number: 531029
Application:1999-2006 Chevy Silverado & 2007 Silverado Classic body style / 1999-2006 GMC Sierra &



Tools Needed: Phillips screwdriver



Step 1: Locate the two phillips screw and remove them with a phillips screwdriver.



Step 2: Pull off the 3rd brake light from the vehicle.



Step 3: Locate the wire harness and unplug it from the light.





Step 4: Take out the new Anzo light and peel off the backing from the blue resistor and place inside the housing.



Step 5: Plug in the new Anzo 3rd brake light.



Step 6: Screw in the light using the two phillips screw removed from step 1.



Step 7: Test all functions making sure everything works before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

© 2008 AnzoUSA™. All rights reserved.