Baja Designs 448165 Installation Instructions

448165

Part number: 448165

trailfortress.com/baja-designs-dodge-ram-s2-sae-fog-pocket-light-kit-448165

Scan for fitment, price and install help

Dodge Ram 2500/3500 LED (19-On)
S2 Fog Pocket Kit
44-8042, 44-8043, 44-8165, 44-8170



2950 Norman Strasse Rd • San Marcos • CA • 92069

Phone 760-560-2252 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com

trailfortress.com/baja-designs-dodge-ram-s2-sae-fog-pocket-light-kit-448165

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.
These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:
Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.
Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.
Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.
Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:
Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.

Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.

trailfortress.com/baja-designs-dodge-ram-s2-sae-fog-pocket-light-kit-448165

Dodge 2500/3500 Squadron Fog Pocket kit

Tools Required

- 4mm Allen wrench
- 2.5mm Allen wrench
- Flathead Screwdriver
- Multimeter or circuit test light (optional)
- 7mm Socket wrench
- 10mm Socket wrench
- 7/16” Wrench
- 7/16” Socket wrench

1. Disconnect harness connector clipped on driver side fog lamp bracket:
   (1a) Pull grey plug lock and unplug the connector.
   (1b) Pry the detent, then remove the other connector.





2. Pull down the red connector lock and squeeze detent (starred) to remove plug.



*Image may differ slightly.

3. Remove 4 bolts with 10mm Socket wrench (Circled).



4. Remove the fog lamp from vehicle. Repeat steps 2-3 for passenger side.

5. Remove the four fog lamp screws with the 7mm wrench. Repeat for other side. Remove OEM fog light from the factory mounting bracket.



6. Assemble the S2 lights to their brackets with the provided hardware and 4mm Allen wrench. Remove bezel bolts with the 2.5mm Allen wrench and rotate the bezel 180 degrees. Tighten bezel bolts. With the ¼” hardware and 7/16” wrench and socket, mount the S2s into the Baja designs fog light bracket.



7. Mount the new fog lamp assemblies into the fog mounting bracket with two of the four screws from step 5. Repeat for the other side.

8. Mount the fog lamp assemblies into the vehicle with the 10mm Socket wrench and bolts from step 3.

9. Connect H11 plug ‘n play adapter to lights and OEM connections for both sides.

9. Turn on the vehicle, headlights, and fog lights. Determine which wire on the OEM fog connector has (+) voltage, and (-) ground. Turn vehicle off. The (+) wire will be inserted into (B) and the (-) wire will be inserted into (A).

(B)
(A)



Re-torque all the fasteners after 100 miles.

Your install is now complete! Thank you for choosing Baja Designs.

trailfortress.com/baja-designs-dodge-ram-s2-sae-fog-pocket-light-kit-448165