TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Baja Designs 660300 Installation Instructions

Security Hardware Kit for S2 and Squadron

Part number: 660300

trailfortress.com/baja-designs-s2-squadron-series-security-hardware-kit-660300

Scan for fitment, price and install help

baja designs
The Scientists of Lighting



Security Hardware Kit
Installation Instructions

(PN: 66-0300, 66-0301, 66-0302)

Baja Designs ♦ 185 Bosstick Blvd. ♦ San Marcos ♦ CA ♦ 92069

Phone 760.560.2252 ♦ Fax 760.560.0383

www.bajadesigns.com

trailfortress.com/baja-designs-s2-squadron-series-security-hardware-kit-660300

For part number 66-0300 (S2/Squadron (Pro & Sport), Security Hardware Kit)

Qty	Description
2	M6x16 Socket Pin Head Bolts
1	Socket Pin Head Driver Bit

For part number 66-0301 (Squadron XL, Security Hardware Kit)

Qty	Description
2	¼-20x ½ Socket Pin Head Bolts
1	Socket Pin Head Driver Bit

For part number 66-0302 (OnX6, Security Hardware Kit)

Qty	Description
2	¼-20x ½ Socket Pin Head Bolts
1	Socket Pin Head Driver Bit