TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Borla 60087 Installation Instructions

X-Pipe for Chevrolet Corvette (1997-2004)

Part number: 60087

trailfortress.com/borla-x-pipe-60087

Scan for fitment, price and install help