TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

DV8 Offroad LBJL-04 Installation Instructions

A-Pillar Dual Pod Light Mounts for Wrangler JL & Gladiator

Part number: LBJL-04

trailfortress.com/dv8-offroad-2018-22-jeep-jl-2020-2022-jeep-jt-a-pillar-dual-pod-light-mounts-lbjl04

Scan for fitment, price and install help

6400 SYCAMORE CANYON BLVD.
RIVERSIDE, CALIFORNIA 92507
855-680-9595
WWW.DV8OFFROAD.COM

PRODUCT
INSTALLATION MANUAL

Dual A-Pillar Pod Mounts

2018+ JEEP JL/JT
LBJL-04



TOOLS REQUIRED

- #5 Allen Head
- T40 Torx Bit
- 10mm Wrench

SKILL LEVEL

- Novice/Intermediate
- 1 person

Little skill level required and you can easily install by yourself.

TIME REQUIRED

- 1 Hour

Time to install this should only take about an hour.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

• *Always wear eye protection when operating power tools*

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover

trailfortress.com/dv8-offroad-2018-22-jeep-jl-2020-2022-jeep-jt-a-pillar-dual-pod-light-mounts-lbjl04

STEP 1

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from.

Hardware Included:

(2) M8 x 30mm Allen Head Bolt
(2) M8 Flat Washers
(2) M8 Split Washers



STEP 2

Starting with the passenger side, begin by removing the antenna using your 10mm wrench. This will prevent any damage to your paint when removing the a-pillar panel.





STEP 3

Install the lights onto the brackets using the provided hardware with the lights. Our brackets are designed to accept up to a M10 bolt to mount the light.

Note: We are using two 3" DV8 Elite Pod Lights for our install.



STEP 4

Using your T40 torx bit remove all four bolts located on the a-pillar and cowl, once all bolts are out you may pull off the a-pillar panel.





STEP 5

Hold the bracket over the cowl while you run the wiring to your preference (this can be either into the hood or toward the cowl depending on how you decide to wire your lights).



STEP 6

Once the wires are in place, reinstall the factory a-pillar panel ensuring the wires are side by side near the back of the panel.





STEP 7

Place the bracket onto the panel aligning the two holes on the cowl and the front hole on the a-pillar panel. Loosely install the bolts on the top two holes on the cowl reusing factory hardware.





STEP 8

Use the provided M8 hardware for the bottom hole on the bracket and reuse one of the factory bolts for the rear a-pillar panel mount.



STEP 9

Continue by tightening all bolts in a star pattern (make sure both wires do not get pinched in between the a-pillar and cowl).

Repeat all steps on driver side.



STEP 10

Reinstall your antenna and check to ensure all hardware is secure.



STEP 11

Finish wiring lights to your preference.

You are now done with the install of your new DV8 Dual A-Pillar Pod Mounts.

