TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

ICON Vehicle Dynamics 57625P Installation Instructions

Rear 2.5 VS NR Shock Pair for Toyota Land Cruiser, 0-2 in.

Part number: 57625P

trailfortress.com/icon-vehicle-dynamics-08-up-lc-200-0-2-rear-2-5-vs-nr-pair-57625p

Scan for fitment, price and install help

ICON VEHICLE DYNAMICS ™
7929 Lincoln Ave. Riverside, CA 92504
Phone: 951.689.ICON Fax: 951.689.1016

57625P INSTALLATION INSTRUCTIONS

1-19-2015 REV.A

PART #	DESCRIPTION
57625P	08-UP LAND CRUISER 200 REAR 2.5 VS NR SHOCKS

COMPONENTS INCLUDED

(2) 154853 08+ LAND CRUISER 200 0-2" REAR 2.5 VS NR UPKG	(2) 611007 9/16" MEDIUM DUTY STEM BUSHING KIT

HARDWARE INCLUDED

611007 STEM BUSHING HARDWARE KIT


(2) MED DUTY 9/16" ID STEM BUSHING (1) MED DUTY 9/16" ID STEM WASHER	(1) MED DUTY 12MM ID STEM WASHER (1) M12-1.25 NYLOCK NUT

TOOLS REQUIRED

JACK JACK STANDS TORQUE WRENCH	14MM SOCKET / WRENCH 17MM SOCKET / WRENCH 19MM SOCKET / WRENCH 4.5MM ALLEN WRENCH

TECH NOTES

1. THIS UNIT IS CHARGED WITH 250PSI OF NITROGEN. DO NOT DISCHARGE.



WARNING!

*** READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED SEVERE FRAME, SUSPENSION AND TIRE DAMAGE MAY RESULT TO THE VEHICLE!*

*** ICON VEHICLE DYNAMICS RECOMMENDS THAT YOU EXERCISE EXTREME CAUTION WHEN WORKING UNDER A VEHICLE THAT IS SUPPORTED WITH JACK STANDS.*

INSTALLATION

1. ENSURE TRUCK IS IN GEAR OR IN PARK, SET PARKING BRAKE, TURN OFF ENGINE AND CHOCK REAR TIRES!

2. Jack up the rear of the truck and support with jack stands under the frame rail and remove the wheels.


3. Deactivate the KDSS: on the inside of the left frame rail you will find a hydraulic valve block that the KDSS lines go to. On the bottom there are 2 set screws that are normally in the closed position. Using a 4.5mm allen wrench loosen both set screws 2 turns each. This will allow the suspension to droop equally without the sway bars fighting its movement while work is performed.

4. With a floor jack under the rear end, slightly raise the rear axle housing. Using a 17mm socket/wrench loosen and remove the lower shock bolts. Make sure the axle is well supported. Keep all of the hardware, it will be reused.

5. Using a 17mm socket/wrench disconnect top of the shock: Reach up over the top mount near the coil bucket to access the upper stem nut. This can be a little hard to reach, when loose you may be able to spin the shock to aid in removal.

6. Install the shock stem washer and bushing onto the top of the shock assemblies as follows: washer, bushing, OEM shock mount, bushing, washer, lock nut. Put the lower washer and bushing on the shock stem, raise the shock up into position and install the remaining bushing, washer and lock nut. (Driver and passenger shocks only vary by sticker orientation). **(FIGURE 1)**

FIG.1



7. Using a 19mm socket/wrench, tighten the lock nut so 2-3 threads are showing through the nut.

8. There are 2 spacers that go on either side of the bearing on the lower shock mount stud on the axle. The fit of the spacers and the lower shock bearing is a very tight tolerance. It is common for the stud on the axle to get corroded over time. You may need to clean the stud of buildup prior to installation of the spacers and bearing. Emery cloth or sand paper works best.

9. Slide 1 spacer over the stud then the lower shock bearing followed by the other spacer. To assist in lining up the bearing with the

trailfortress.com/icon-vehicle-dynamics-08-up-lc-200-0-2-rear-2-5-vs-nr-pair-57625p

stud you will have to jack up the axle very slowly so the parts align. You will also need to rotate the inner part of the bearing to be parallel with the stud, this can be easily done using the female head of a 3/8" extension in the bearing for leverage. Use the OE bolt and captive washer to clamp the lower bearing and spacers. Using a 17mm socket/wrench tighten the bolt. [Torque to factory spec]

10. Install wheels [Torque to factory spec] and carefully place vehicle back on the ground.

11. Close the KDSS bypass valve: with the vehicle sitting on the ground and level, screw both set screws in until they bottom. **(FIGURE 2)**

FIG.2



VERIFY ALL FASTENERS ARE PROPERLY TORQUED BEFORE DRIVING VEHICLE.

RETORQUE ALL NUTS, BOLTS AND LUGS AFTER 100 MILES AND PERIODICALLY THEREAFTER.

trailfortress.com/icon-vehicle-dynamics-08-up-lc-200-0-2-rear-2-5-vs-nr-pair-57625p

2.5 VS SERIES SHOCK & COILOVER TECHNICAL INFORMATION

MAINTENANCE

ICON shock absorbers are a high quality rebuildable race style shock absorber designed for optimal performance. With a unit of this caliber on your vehicle, routine maintenance is required to keep them looking and operating in like new condition. Residual oil and assembly lube may be present at all seal paths from the factory out of the box and is considered normal. Pooling of oil however is not acceptable at any time and one should contact the iCON dealer where purchased.

BELOW ARE GUIDELINES BASED ON HOW YOU USE YOUR VEHICLE BUT YOUR MILEAGE MAY VARY:

STREET USE:

- Send in for factory servicing every 40,000 miles or if a leak develops, ride quality decreases, or they begin to make excessive noise.
- Remove any buildup of road salt, mud, or debris from shocks and coil springs anytime accrued
- Clean with mild soap and water with each oil change or anytime you notice build up.
- Wax the cylinders yearly with automotive wax to prevent corrosion.
- Check nitrogen pressure yearly. (252004 charge needle assembly available at any ICON distributor)
- Check bearings for excessive wear yearly.
- **DO NOT** apply any type of lube to the upper and lower bearings.

STREET/DIRT:

- Send in for factory servicing every 15,000 miles or if a leak develops, ride quality decreases, or they begin to make excessive noise.
- Clean with mild soap and water with each oil change, offroad trip, or anytime you notice build up.
- Wax the cylinders yearly with automotive wax to prevent corrosion.
- Check nitrogen pressure each dirt outing. (252004 charge needle assembly available at any ICON distributor)
- Check bearings for excessive wear yearly.
- **DO NOT** apply any type of lube to the upper and lower bearings.

DIRT USE:

- Send in for factory servicing every 1,000 miles.
- Check nitrogen pressure each outing. (252004 charge needle assembly available at any ICON distributor)
- Remove any buildup of mud or debris from shocks and coil springs after every outing.

SELF-SERVICE:

- Contact ICON for service kits & tools at (951) 689-4266.

PRODUCT REGISTRATION

Please visit: http://www.iconvehicledynamics.com/tech-support/registration/ to register your product.

ICON VEHICLE DYNAMICS SHOCK ABSORBER WARRANTY

This shock absorber has a 1 year warranty against any manufacturer's defects. If a shock fails within the initial year of ownership, the shock must be shipped to ICON Vehicle Dynamics for inspection and service. If a shock is inspected and it has been determined the shock failed due to neglect, damage caused by improper installation or any other reason besides "normal wear and tear", the owner of said shock is responsible for all service costs. This includes labor, parts, and shipping.

ICON Vehicle Dynamics warrants to the original retail purchaser who owns the vehicle on which the product was originally installed. ICON Vehicle Dynamics does not warrant the product for finish, alterations, modifications and/or installation contrary to ICON Vehicle Dynamics instructions. ICON Vehicle Dynamics products are not designed, nor are they intended to be installed on vehicles used in race applications, for racing purposes or for similar activities. (A "race" is defined as any contest between two or more vehicles, or a contest of one or more vehicles against the clock, whether or not such contest is for a prize). This warranty does not include coverage for police or taxi vehicles, race vehicles, or vehicles used for government or commercial purposes. Also excluded from this warranty are sales outside of the United States of America and Canada.

ICON Vehicle Dynamics' obligation under this warranty is limited to the repair or replacement, at ICON Vehicle Dynamics' discretion, of the defective product. Any and all costs of removal, installation or re-installation, freight charges and incidental or consequential damages are expressly excluded from this warranty. Items that are subject to wear are not considered defective when worn and are not covered.

ICON Vehicle Dynamics components must be installed as a complete kit as shown in our current application guide. Any substitutions or exemptions of required components will immediately void the warranty. Some finish damage may happen to parts during shipping and is not covered under warranty.

This warranty is expressly in lieu of all other warranties expressed or implied. This warranty shall not apply to any product that has been improperly installed, modified or customized subject to accident, negligence, abuse or misuse.

To send a shock in for warranty please visit our website http://www.iconvehicledynamics.com/tech-support/shock-service/

ICON VEHICLE DYNAMICS

PERFORMANCE SUSPENSION SYSTEMS AND SHOCK ABSORBERS

7929 Lincoln Ave. Riverside, CA 92504 Phone: 951.689.ICON Fax: 951.689.1016

www.iconvehicledynamics.com

FOLLOW US ON FACEBOOK!

trailfortress.com/icon-vehicle-dynamics-08-up-lc-200-0-2-rear-2-5-vs-nr-pair-57625p