Rough Country 100064C Installation Instructions

100064C

Part number: 100064C

trailfortress.com/rough-country-air-spring-kit-w-compressor-100064c

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

921100060

10006BAG

CHEVY 2001-10 2500/3500 Rear Air Spring Kit

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

⚠NOTICE Airbags will not increase the maximum load capacity.

Kit Contents:

Air Bags x2
Upper Bracket x2
Lower Bracket x2
Lower Strap x2
Heat Shield x1
Brake line Bracket x1
90° Fitting x2
Inflation Valve x2

Lifted Application Only
Spacer x2

Tools Needed:

7/32 Allen Wrench
9/16" Socket/Wrench

Hardware Included:

3/8" x 3/4" Flat Head Bolts x4
3/8" x 2" Carriage Bolts x4
1/4" DOT Air Line x20ft
Hose Clamp x2
3/8" x 1-1/2" Bolts x4
3/8" x 1" Bolts x4
3/8" Lock Washers x4
3/8" Flat Washers x8
3/8" Flange Nut x8
5/16" x 1" Bolts x2
5/16" Flat Washers x2
5/16" Flange Nut x2
Clamp x2
Zip Ties x6

Lifted Application Only
3/8" x 1" Bolts x4
3/8" Flat Washers x4
3/8" Lock Washers x4



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs