Rough Country 10023C Installation Instructions

Air Spring Kit with Compressor for Ford Super Duty 4WD (2005-2016)

Part number: 10023C

trailfortress.com/rough-country-air-spring-kit-w-compressor-10023c

Scan for fitment, price and install help

921100230

ROUGH COUNTRY
SUSPENSION SYSTEMS®

FORD 2005-16 F-250/F-350 Rear Air Bag Kit

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

Kit Contents:

Air Springs x2
Dr Upper Air Spring Mount x1
Pass Upper Air Spring Mount x1
Upper Air Spring Spacers x6
Emission Line Bracket x1
Lower Air Spring Mounts x2
Lower Air Spring Mounts Top x2
Lower Straps x2
Heat Shield x1

Tools Needed:

3/8” Socket/Wrench
9/16” Socket/Wrench
3/4” Socket/Wrench

Hardware Included:

1/4” x 1” Hex Bolts x2
1/4” Flat Washers x4
1/4” Lock Nuts x2
3/8” x 4” Carriage Bolts x4
3/8” x 2” Carriage Bolts x2
3/8” x 1” Hex Bolts x20
3/8” Lock Washers x8
3/8” Flat Washers x20
3/8” Flange Lock Nuts x16
1/2” x 3-1/2” Hex Bolts (for gooseneck)
1/2” x 1-1/2” Hex Bolts (non-gooseneck)
1/2” Lock Nuts x2
1/2” Flat Washers x8
Nuts x2
Zip Ties x6
Hose Clamps x2
Loop Clamp x1



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs