Rough Country 100347C Installation Instructions

Air Spring Kit with 4 Inch Spacer for Chevy & GMC HD (2020-2025)

Part number: 100347C

trailfortress.com/rough-country-air-spring-kit-w-compressor-100347c

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

921100340

CHEVY 2020-23 2500/3500 REAR AIR SPRING KIT

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.

Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Periodically check all hardware for tightness.

⚠NOTICE Airbags will not increase the maximum load capacity.

KIT CONTENTS:
Dr. Side Upper Bracket
Pass. Side Upper Bracket
2 - Lower Bracket
2 - Lower Strap
Heat Shield
2 - Air Spring
20' - DOT Air Line

TOOLS REQUIRED:
13mm Wrench or Socket
14mm Wrench or Socket
7/32 Allen Wrench
21mm Wrench or Socket
13/64" Drill
9/16" Wrench or Socket
Drill Motor
Thread Tape/Sealant

Hardware Included:
2 - Hose Clamp
2 - 90° Air Fitting
2 - Inflation Valve
8 - 3/8" x 3/4" Flat Head Bolt
4 - 3/8" x 2" Carriage Bolt
2 - 3/8" x 1" Self Tapping Bolt
3 - 8mm x 20mm Bolt
3 - 8mm Flat Washer
8 - 3/8" Flange Lock Nut
4 - 3/8 x 6 1/2" Bolt
2 - 3/8" x 3 5/8" x 4 3/4" U-Bolt
2 - 3/8" Nut Plate
4 - 3/8" Flat Washer
4 - 3/8" Lock Washer



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs