TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 10402 Installation Instructions

Vertex Coilover Adjusting Wrench for GM, Ram and Ford Trucks

Part number: 10402

trailfortress.com/rough-country-vertex-coilover-adjusting-wrench-10402

Scan for fitment, price and install help

921104020

VERTEX Coilover Adjusting Wrenches

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.

Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Check and retighten wheels at 50 miles and again at 500 miles. Periodically check all hardware for tightness.

WARNING **To prevent damage to the shock or bodily harm, All of the load must be removed from the coil spring seat before the jam nut is loosened.**

KIT CONTENTS:
1-COILOVER ADJUSTING WRENCH

TOOLS NEEDED:
FLOOR JACK
JACK STANDS
OUTER COIL COMPERSSOR
OR A
WALL MOUNTED STRUT
COMPRESSOR
WHEEL CHOCKS



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs