Rough Country 1043 Installation Instructions

1043

Part number: 1043

trailfortress.com/rough-country-brake-pump-relocation-bracket-1043

Scan for fitment, price and install help



92104300

JEEP JK CANISTER RELOCATION BRACKET

Thank you for choosing Rough Country for your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Be sure you have all needed parts and know where they go. Please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

If question exist we will be happy to answer any questions concerning the design, function, and correct use of our products by calling 1-800-222-7023.

Tools Needed:
10mm Socket / Wrench
3/4 Socket / Wrench
Reciprocating Saw
Grinder



INSTALLATION INSTRUCTIONS

1. All steps are performed after the front bumper is removed and ready for Rough Country Bumper installation.
2. Remove the canister from the frame using a 10mm socket / wrench. **See Photo 1.** Remove the connectors and lines from the canister. Use care not to damage any lines or connectors. Retain the factory 10mm nuts.



ROUGH COUNTRY SUSPENSION SYSTEMS