TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 1044 Installation Instructions

0-3.5in Front Track Bar for Jeep Wrangler (1997-2006)

Part number: 1044

trailfortress.com/0-3-5in-front-track-bar-jeep-wrangler-rough-country-1044

Scan for fitment, price and install help



92104400

TJ FORGED FRONT ADJ TRACK BAR KIT FOR 0”-3 1/2” LIFT

Thank you for choosing Rough Country for your Jeep off road needs.

Please read all the instructions before beginning the installation.

PRODUCT USE INFORMATION

We will be happy to answer any questions regarding our products by calling us @ 800-222-7023. Rough Country will not be responsible for any product that is altered. **This kit is for use with vehicles lifted 0”- 3” of lift.**

TOOLS NEEDED

DRILL MOTOR
13/32” DRILL BIT
15MM SOCKET / WRENCH
18MM SOCKET / WRENCH
19MM SOCKET / WRENCH
9/16” SOCKET / WRENCH
5/8” WRENCH
11/16” WRENCH

KIT CONTENTS

1-TRACK ROD BRACKET
1-ADJ FORGED TRACK BAR

1-POLY BAG CONTAINING:

1-10MM X 70MM BOLT
2-3/8” FLAT WASHERS
1-10MM LOCK NUT
1-1/2” X 1 3/4” BOLT
1-1/2” FLAT WASHER
1-1/2” LOCK NUT
1-12MM X 80MM BOLT
1-12MM LOCK NUT
1-3/8” X 2” BOLT
2-3/8” FLAT WASHERS
1-3/8” LOCK NUT



INSTALLATION INSTRUCTIONS

1. Remove the track rod from the axle and from the frame using a 15mm (axle) & 18mm wrench (frame).
2. Grind the back side of the mount smooth to allow the track rod bracket to be installed. **See Photo 1.**
3. Install the new track rod bracket on the frame as shown in **Photo 2** using the supplied 1/2òx 1 3/4òbolt, washer & nut in the stock mount. Tighten using a 19mm Socket & wrench. **View from the passenger side.**




PHOTO 1

GRIND BRACKET FLAT




PHOTO 2

INSTALL 1/2” X 1 3/4” BOLT , WASHERS NUT

4. Using the bracket as a quide, drill the upper hole using a 13/32òdrill bit. **See Photo 3.**
5. Install the supplied 3/8òx 2òbolt in the drilled hole with the washers & nut. Tighten using a 9/16òsocket & wrench. **See Photo 4.**





6. Install the track rod on the frame with the supplied 12mm x 80mm bolt, washer & nut. Do not tighten at this time. **See Photo 5.**
7. Swing up the track rod and install in the track rod bracket with the supplied 10mm bolt and nut. Do not tighten at this time. **See Photo 6.**





8. Measure front axle to see if the body is centered over the axle, if not turn the adjustment collar until the front axle is centered. Next tighten the clamps on the adjustment collar with a 11/16òand 5/8òwrench. **See Photo 7.**
9. Tighten the axle mount to factory specifications using a 15mm wrench.
10. Tighten the frame mount using a 18mm & 19mm wrench.



POST INSTALLATION

1. Check all fasteners for proper torque. Check to ensure there is adequate clearance between all rotating, mobile, fixed and heated members. Check steering for interference and proper working order.
2. Re torque all fasteners after 500 miles. Visually inspect components and re torque fasteners during routine vehicle service.

Thank you for purchasing a Rough Country Suspension Lift Kit.

trailfortress.com/0-3-5in-front-track-bar-jeep-wrangler-rough-country-1044