TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 10532 Installation Instructions

5-Inch Rear Tube Fender Flares for Jeep Wrangler (2007-2017)

Part number: 10532

trailfortress.com/5-inch-rear-tube-fender-flares-jeep-wrangler-rough-country-10532

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

10532

Jeep JK Rear Flat Fenders

Thank you for choosing Rough Country

Please read instructions before beginning installation. Check the kit hardware against the parts list and product layout. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

If questions exist we will be happy to answer any questions concerning the design, function, and correct use of this product.

⚠NOTICE Painted fenders cannot be returned.

Kit Contents:

2– Rear Fenders
- 8-6mm x 25mm Button Head Bolts
- 8-6mm Flat Washers
- 8-6mm Nutserts
- 4-8mm x 25mm Button Head Bolts
- 4-8mm Flange Nuts
- 4-8mm Flat Washers
- 1-Nutsert Installation Tool



Tools Needed:
Pliers
Flat Screwdriver
3/16” Allen
10mm Socket
13mm Wrench
5/16” Drill
Drill Motor
Ratchet
Grinder
Cutoff Wheel
Body Saw

INSTALLATION

1. Place vehicle on a flat surface and set emergency brake.
2. Using a flat screwdriver or clip removal tool, remove the 6 plastic clips from the factory fender liner. Retain for reuse. **See Photo 1.**
3. Firmly grasp the front of the factory fender and lift up to release the mounting clips, working your way to the rear of the fender. **See Photo 2.**



