Rough Country 10543_B Installation Instructions

Cold Air Intake for Cadillac Escalade, ESV & EXT (2009-2014)

Part number: 10543_B

trailfortress.com/cold-air-intake-cadillac-escalade-esv-ext-rough-country-10543-b

Scan for fitment, price and install help

921054300

ROUGH COUNTRY
SUSPENSION SYSTEMS®

2009-13 GM1500 5.3L / 14 ESCALADE Cold Air Intake

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:
3/8" PVC Hose x1
Intake Coupler x1
Intake Tube / Filter coupler x1
Heat Shield x1
Heat Shield Rubber Trim x1
Air Filter Flange x1
Air Filter x1
Intake Tube x1
90Deg. Fender Bracket x1

TOOLS NEEDED:
Flat Head Screw Driver
10mm socket
1/2" Socket
5/8 wrench
5/8 Drill
Drill Motor
T15 Torx Bit
Ratchet

HARDWARE INCLUDED:
Air Filter Clamp x1
1 1/4 Hose Clamp x2
3.5" Clamp x3
4" Clamp x1
Barbed Fitting x1
6mm-1.00 x 16 hex head bolt x1
6mm x 25mm Hex Head Bolt x1
6mm Large OD Flat Washer x2
6mm Flat Washer x3
6mm Lock Nut x 2
5/16-18 x 1" Hex Head Bolt x2
5/16 Flat Washer x2
5/8"Rubber Insert Grommet x2
6mm-1.00 x 16mm Button Head x2
1/4" Flat Washers x2
1/4" Lock Washer x2
4mm Screws x2

