TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 10546PF Installation Instructions

Cold Air Intake with Pre-Filter for Tundra 5.7L (2012-2021)

Part number: 10546PF

trailfortress.com/cold-air-intake-tundra-5-7l-rough-country-10546pf

Scan for fitment, price and install help

921105460

ROUGH COUNTRY
SUSPENSION SYSTEMS®

Toyota 2012-19 Tundra V8-5.7L Cold Air Intake

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

⚠NOTICE **NOT FOR SALE IN CALIFORNIA**

KIT CONTENTS:
3.5” Clamp x1
4” Clamp x3
Air Filter Clamp x1
3.5” to 4” Rubber Adapter x1
Intake Tube x1
4” Flex Tube x1
Heat Shield x1
Seal x1
Filter Adapter x1
Air Filter x1
2 Hole Bracket x1
90 deg. Bracket x1
45 deg. Bracket x1
1/8”-1/4”NPT Barbed Hose Fitting x1
1/2”-1/4”NPT Barbed Hose Fitting x1
1/2” Double Barbed Coupler x1
1/2” I.D. x 7”L. Hose x1
Bracket Spacers x4

TOOLS NEEDED:
Plyers
Flat Head Screwdriver
Phillips Screwdriver
2.5 mm Allen Wrench
4mm Allen Wrench
9/16 Wrench
10mm Wrench and Socket
Razer Knife

HARDWARE INCLUDED:
Stud x1
Hex Stud Extension x1
4mm x 8mm Button Head Bolt x2
6mm x 16mm Button Head x2
6mm lock washers x 5
6mm x 16mm Hex Head Bolt x3
6mm x 20mm Hex Head Bolt x4
6mm Flat Washer x13
6mm Nylock Nut x4



RC ROUGH COUNTRY