Rough Country 10547PF Installation Instructions

Cold Air Intake with Pre-Filter for Tacoma 3.5L (2016-2023)

Part number: 10547PF

trailfortress.com/cold-air-intake-tacoma-3-5l-rough-country-10547pf

Scan for fitment, price and install help



TOYOTA 2016-19 Tacoma 3.5L Cold Air Intake Kit

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:
Air Filter x1
Filter Clamp x1
Filter Adapter x1
Coupler Clamps x4
Flex Tube x1
Intake Tube x1
Rubber Coupler x1
Heat Shield Bracket x1
Rubber Seal x1
5/8” Barbed Fitting x1
Shield Bracket x1

TOOLS NEEDED:
2.5mm Allen Wrench
4mm Allen Wrench
24mm Wrench
10mm Wrench or Socket
12mm Wrench or Socket
Flat Bit Driver
Philipps Bit Driver
Plyers

HARDWARE INCLUDED:
4mm Button Head Bolts x2
6mm-1.0 x 12mm Button Head x2
6mm-1.0 x 12mm Hex Head x2
6mm-1.0 x 16mm Hex Head x1
6mm-1.0 Nylock Nut x1
6mm Lock Washers x4
6mm Flat Washers x6
6mm Rubber Mounts x2
Double Stud Rubber Mount x1
8mm Lock Nut x1
8mm Flat Washer x1



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs