Rough Country 10561 Installation Instructions

10561

Part number: 10561

trailfortress.com/rough-country-3-6l-throttle-body-spacer-kit-10561

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

JEEP JK / JL 3.6L THROTTLE BODY SPACER

Thank you for
choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this kit. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this kit without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have the needed tools.

Kit Contents

1-Gasket
1-Throttle Body Spacer
1-Bag Containing:
- 4-M5.5 x 50mm
- 4-Flat Washers

Tools Needed
T-20 Torx Bit
Flat Head Screwdriver
10mm Socket



Installation Instructions

1. Remove the hose from the intake as shown using a flat head screwdriver. **See Photo 1.**
2. Remove the 4 bolts securing the throttle body using a T-20 bit. **See Photo 2.**
3. Clean all the factory components before re-assembly.



