TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 10581 Installation Instructions

Full Body Armor Kit for 1997–2001 Jeep Cherokee XJ

Part number: 10581

trailfortress.com/full-body-armor-kit-jeep-cherokee-xj-rough-country-10581

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

10571BAG

JEEP 84-01 XJ Rear Quarter Panel Armor

Thank you for choosing Rough Country.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

⚠ NOTICE NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

Tools Needed:
6mm Allen
10mm Socket & Wrench
1/4” Deep Well Socket
7/16” Wrench
1/2” Wrench
Heat Gun
3/16” Drill
Painters Tape
25/64” or W size Drill
Drill Motor
5/32” Allen
Torque Wrench