TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 10613 Installation Instructions

HD Steering Kit with N3 Stabilizer for Jeep Cherokee & Wrangler

Part number: 10613

trailfortress.com/hd-steering-kit-jeep-cherokee-wrangler-rough-country-10613

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

921106040

10604BAG

JEEP TJ/XJ/MJ/ZJ HD Steering

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.

Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Check and retighten wheels at 50 miles and again at 500 miles. Periodically check all hardware for tightness.

KIT CONTENTS:

1– 25" Drag Link
1– 42" Tie Rod Link
1– Upper LH Thread Tie Rod End
1– Lower RH Thread Tie Rod End
1– Passengers Side LH Thread Tie Rod End
1– Drivers Side RH Thread Tie Rod

HARDWARE INCLUDED:

2– Left Hand Jam Nuts
2– Right Hand Jam Nuts
4– Castle Nuts
4– Cotter Pins

TOOLS NEEDED:

15mm wrench and socket
18mm wrench and socket
19mm wrench and socket
1 1/6 wrench
1 1/4 wrench
Side Cutting Pliers
Drill motor
5/8 Drill
7° Reamer
Ratchet
Tape measure



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs

RC ROUGH COUNTRY