TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 1069 Installation Instructions

Rear Traction Bar Kit for Silverado 1500 and Sierra 1500 4WD

Part number: 1069

trailfortress.com/rear-traction-bar-kit-silverado-1500-and-sierra-1500-4wd-rough-country-1069

Scan for fitment, price and install help

92106900

ROUGH COUNTRY SUSPENSION SYSTEMS®

1069BAG1

07-15 GM 1500 Traction Bar Kit

Thank you for choosing Rough Country for all your suspension needs.

⚠WARNING Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read instructions before beginning installation. Check the kit hardware against the kit contents. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

⚠WARNING Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and correct use of our products by calling our toll free number @ 800-222-7023.

⚠WARNING DEALER AND VEHICLE OWNER

Install the supplied "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

NOTICE By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

Tools Needed:
Wheel Chocks
Ratchet
1 1/8" socket

Torque Specs:

Size	Grade 8
1/2"	90 ft/lbs
9/16"	130 ft/lbs
5/8"	175 ft/lb

Kit Contents:
2-Axle Brackets
2-Frame Brackets
2-Flag Nuts
2-Traction Bars
1-1069Bag2

1069Bag2:
2-Heim Ends
2-Heim Sleeves
2-Heim Jam Nuts
4-1/2" x 1 1/2" Bolts
2-12MM X 55MM Bolts

INSTALLATION INSTRUCTIONS

1. Locate the supplied template to the factory hole in frame shown in **Photo 1** and mark hole locations.
2. Drill the marked holes with a 17/32" drill bit. **See Photo 2**.



Locate factory hole and align template



Drill holes with a 17/32" drill bit