TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

# Rough Country 10762 Installation Instructions

EXO Winch Mount Kit for Ford F-150 (2009-2025)

Part number: 10762

trailfortress.com/exo-winch-mount-kit-ford-f150-rough-country-10762

Scan for fitment, price and install help

921107620

ROUGH COUNTRY SUSPENSION SYSTEMS®

# FORD F150 09-18 EXO Bumper

**Thank you for choosing Rough Country for all your vehicle needs.**

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning the design, function, and correct use of our products

**⚠NOTICE** **Rough Country LED lights are for off-road use only.**

**If factory equipped, winch bumper may interfere with parking, proximity and external cruise control sensors.**

**KIT CONTENTS:**
- 1-EXO Front Bumper w/ Light Mount
- 2– 2” Flush Mount LED Cubes
- 1– Single Row 20” LED
- 1– Dr Side Frame Bracket
- 1– Pass Side Frame Bracket
- 2-D-rings

**HARDWARE INCLUDED:**
- 2-12mm x 120mm Bolts
- 6-1/2” Flat Washers
- 8-Lock Washers
- 2-1/2” Lock Nuts
- 8-12mm x 35mm Bolts
- 4-12mm Flat Washers
- 4-12mm Lock Nuts

**TOOLS NEEDED:**
- Pry Tool/Flat Head Screwdriver
- 15mm Socket/Wrench
- 19mm Socket/Wrench
- 3/4” Socket



## INSTALLATION INSTRUCTIONS

1. Remove the front tow hook bolt and loosen the rear bolt using a 15mm socket. Slide the tow hook free and remove from the vehicle. **Do not remove the rear bolt!! See Photo 1**.
2. Install the passenger side bracket as shown in **Photo 2** with the supplied 12mm x 35mm bolts, lock washers and flat washers in the front hole.
3. After installing the front bolt, remove the rear bolt and replace with the 12mm x 35mm bolt, lock washers and flat washers. Slightly tighten with a 19mm wrench but do not fully tighten at this time to allow for adjustment. Repeat for Driver side.




