TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 10783 Installation Instructions

LED Front Bumper for F-250/F-350 Super Duty (2011-2016)

Part number: 10783

trailfortress.com/led-front-bumper-f250-f350-super-duty-rough-country-10783

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

921107830

FORD 2011-16 F-250 Front Bumper

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Periodically check all hardware for tightness.

KIT CONTENTS:

1-Front Bumper
1-Drivers Side Bracket
1-Passengers Side Bracket
1-License Plate Bracket
2-Sets of 2" Square LED Lights
1-20" LED Light

TOOLS NEEDED:

13mm wrench or socket
17mm wrench and socket
18mm wrench and socket
19mm wrench and socket
Long Nose Plyers
Rachet

HARDWARE INCLUDED:

2-6mm x 20mm Button Screw
2-6mm Lock Nut
4-6mm Flat Washer
4-8mm Lock Washer
6-8mm Flat Washer
2-8mm Hex Nut
2-8mm x 16mm Hex Bolt
2-8mm x 25mm Hex Bolt
4-12mm x 35mm Hex Bolt
4-12mm Lock Washer
8-12mm Flat Washer
4-12mm Hex Nut



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs