Rough Country 10785 Installation Instructions

LED Front Bumper for Ram 2500 and 3500 (2011-2018)

Part number: 10785

trailfortress.com/rough-country-front-bumper-10785

Scan for fitment, price and install help

921107850

ROUGH COUNTRY SUSPENSION SYSTEMS®

2010-18 RAM 2500 FRONT BUMPER

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Periodically check all hardware for tightness.

KIT CONTENTS:
1– Front Bumper
1– Drivers Side Bracket
1– Passengers Side Bracket
1-License Plate Bracket
2—Sets of 2" Cube LED'S
1-20" LED Light

TOOLS NEEDED:
15mm wrench or socket
19mm wrench and socket
22mm wrench and socket
Ratchet
2.5 Allen Wrench

HARDWARE INCLUDED:
12-4mm x 10mm Button Screw
4-6mm Flat Washer
2-6mm x 20mm Button Screw
2-6mm Lock Nut
4-8mm Lock Washer
6-8mm Flat Washer
2-8mm Hex Nut
2-8mm x 16mm Hex Bolt
2-8mm x 25mm Hex Bolt
6-12mm x 40mm Hex Bolt
8-12mm x 50mm Hex Bolt
16-12mm Flat Washer
8-12mm Lock Washer
12-12mm Flat Washer
6-12mm Lock Nut
8-12mm Hex Nut



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs