TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 1082 Installation Instructions

Rear Bar Pin Flag Nut for 1984-2001 Jeep Cherokee

Part number: 1082

trailfortress.com/rear-bar-pin-flag-nut-jeep-cherokee-rough-country-1082

Scan for fitment, price and install help

92108200

ROUGH COUNTRY SUSPENSION SYSTEMS®

84-01 JEEP XJ REAR BAR PIN FLAG NUT

Thank you for choosing Rough Country for your Jeep off road needs.

Please read all the instructions before beginning the installation.

PRODUCT USE INFORMATION

We will be happy to answer any questions regarding our products by calling us @ 800-222-7023. Rough Country will not be responsible for any product that is altered.

KIT CONTENTS

2-REAR UPPER BAR PIN FLAG NUTS
1-POLY BAG CONTAINING:
4-5/16" X 1" BOLTS
4-5/16" FLAT WASHERS



TOOLS NEEDED

13mm wrench
5/8" Socket / Wrench
Air Hammer

INSTALLATION INSTRUCTIONS

1. After the shock absorber has been removed from the vehicle. **See Photo1**
2. Using an air hammer, knock out factory welded in nuts. **See Photo 2**.



