TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 1096 Installation Instructions

0.25-Inch Wheel Spacers for Dodge/Ram 1500 (2009-2024)

Part number: 1096

trailfortress.com/rough-country-0-25-inch-wheel-spacers-1096

Scan for fitment, price and install help

1/4” WHEEL SPACER KIT FOR 5-5.5” WHEEL PATTERN

Thank you for choosing Rough Country for all your suspension needs.=
Professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install these wheel spacers without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.
Please read instructions before beginning installation. Also please review tools needed list and make sure you have needed tools.
Important Note: Spacers must be periodically checked to ensure tightness.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

Kit Contents:

Part #1096 Qty 2-1/4ö Wheel Spacers



Tools Needed:
Torque Wrench
Floor Jack
Jack Stands
Sockets
Socket wrench

Installation Instructions

1. Chock the tires and jack up the vehicle.
2. Remove the lug nuts and remove the tire and wheel. If retaining clips are present they must be removed for the spacer to sit flat on the rotor surface. **Note: Failure to remove the factory retaining clips on the wheel studs could result in a wheel /tire vibration.**
3. Install the wheel spacers as shown. **See Photo 3.**
4. Reinstall the wheels and tighten to manufacturer specifications using a 19mm wrench. **DO NOT EXCEED MANUFACTURER SPECIFICATIONS.**



Post Installation

- **Wheels must be re-torqued periodically. Visually inspect components and re torque fasteners during routine vehicle service.**