Rough Country 11003A Installation Instructions

11003A

Part number: 11003A

trailfortress.com/rough-country-srx2-adj-aluminum-step-11003a

Scan for fitment, price and install help

921120020

ROUGH COUNTRY
SUSPENSION SYSTEMS®

GM 2019-21 1500 Crew Cab Aluminum Step Extrusion Brackets

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

Kit Contents:
Step Rails x2
Front End Caps x2
Rear End Caps x2
Dr Side Brackets x3
Pass Side Brackets x3
Steps x4

Tools Needed:
13mm Socket/Wrench
5mm Allen Wrench

Hardware Included:
8mm x 25mm Bolts x48
8mm Oversized Washers x12
8mm Lock Nuts x30
8mm Finish Nuts x12
8mm x 10mm Button Head x12



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs