Rough Country 110504 Installation Instructions

Bolt-On Rear Bumper with LED Lights for Jeep Cherokee (1984-2001)

Part number: 110504

trailfortress.com/rough-country-rear-bumper-110504

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

110504BAG

JEEP XJ REAR BUMPER

Thank you for choosing Rough Country

Please read instructions before beginning installation. Check the kit hardware against the parts list and product layout. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

If questions exist we will be happy to answer any questions concerning the design, function, and correct use of this product.

The installer must verify that the mounting kit does not interfere with the factory air bag sensors, which must not be relocated or modified in any way. The vehicles are bag system may not operate properly if the winch mounting kit is not mounted in compliance with the vehicle manufacturers recommendations.

Winch mounting should only be performed on vehicles with standard OEM bumpers.

Kit Contents:
1– Rear Bumper
2– D-Rings
1-Pair 2” LED Flush Mount Lights
1– 110504Bag1 including:
- 8-10mmx25mm Bolts
- 8-10mm Flat Washers
- 16-1/2” x 1.5” Bolts
- 22-1/2” Flat Washers
- 8-1/2” Nylock Nuts



Tools Needed:
4mm Allen
10mm Wrench
15mm Socket
17mm Socket
19mm Socket
3/4” Socket
Various Drills
Drill Motor
Ratchet
Torque Wrench

INSTALLATION

1. Place vehicle on a flat surface and set emergency brake.
2. Using a 19mm socket, remove the 8 bolts holding the hitch and gas tank skid. **See Photo 1.**
3. Remove the hitch and gas tank skid from the Jeep.
4. (Bumper has been removed to show bolt location) Using a 15mm socket, remove the bumper & brackets as 1 unit. **See Photo 2.**



