TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.


Rough Country 1112 Installation Instructions

Sway Bar Links for Nissan Titan & Titan XD (2004–2024)

Part number: 1112

trailfortress.com/rough-country-sway-bar-links-1112

Scan for fitment, price and install help



9111200

Nissan Titan Sway Bar Link Kit

Thank you for choosing Rough Country for all your suspension needs.

This Sway Bar Link kit is for use on 2-3" lifted applications.

Professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this kit without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Be sure you have all needed parts and know where they go. Also please review the tool list and make sure you have the necessary tools to install the kit.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service life.

Kit Contents:

2-Sway Bar Links

1-Poly Bag:

- 4-12mm x 65mm Bolts
- 4-12mm Sleeves
- 4-12mm Lock Nuts
- 2-Flat Washers


Tools Needed:


18 mm Wrench
19 mm Socket / Wrench
17 mm Socket / Wrench
15 mm Socket / Wrench



INSTALLATION INSTRUCTIONS

1. Using a 17mm wrench, remove the sway bar nuts from the sway bar as shown in **Photo 1** and the axle.
2. Install the supplied sleeves in the sway bar link bushings and install on the sway bar and the axle with the supplied 12mm x 65mm bolts and lock nuts. **NOTE: The washer will install on the upper sway bar link as shown on the head of the bolt. See Photo 12.** Tighten using a 18mm & 19mm wrench.





Post Installation

Check all fasteners for proper torque. Check to ensure there is adequate clearance between all rotating, mobile, fixed and heated members. Check steering for interference and proper working order