TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 11201 Installation Instructions

2-Inch Air Ride Lift Kit for Escalade, Tahoe, and Yukon

Part number: 11201

trailfortress.com/2-inch-air-ride-lift-kit-escalade-tahoe-and-yukon-rough-country-11201

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

921112010

GM 2022 Tahoe 2” Kit W/ Air Ride

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:
Lower Strut Spacers x4
Ride Height Sensor Brackets x2
Rear Ride Height Sensor Brackets x2

TOOLS NEEDED:
5mm Allen Wrench
hammer
Small pry bar
10mm socket and wrench
13mm socket
17mm socket and wrench
18mm socket
21mm socket
36mm socket

HARDWARE INCLUDED:
Front Hardware 1317BAG1:
10mm x 85mm bolts x4
SAE Flat washers x4
10mm nuts x4
6mm Nylock nuts x2
6mm x 14mm bolts x2

Rear Hardware 11201BAG:
6mm x 12mm Bolts x2
6mm Nylock Nuts x2
6mm Flat Washers x 4



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs