TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 1126 Installation Instructions

High Clearance Skid Plate for Jeep Wrangler 4WD (1997-2006)

Part number: 1126

trailfortress.com/rough-country-high-clearance-skid-plate-1126

Scan for fitment, price and install help



92112600

97-06 JEEP TJ HIGH CLEARANCE SKID PLATE

Thank you for choosing Rough Country for your suspension needs.

Please read Information below!!

Motor mount kit Part # 1156 & 1 1/4" Body Lift Part # 1157 is needed to install this high clearance transfer case skid plate. Failure to install these kits could result in damage to the vehicle created by lack of clearance between the motor / transmission to the body. Rough Country insists installing these kits before the high clearance skid plate is installed to gain clearance and avoid damage to components.

Please note if this skid plate is used with Rough Country's Long arm kit, longer bolts will be needed to secure the skid plate to the frame.

If installing on a Rubicon, part # 1123 is required to remount the compressor to the skid plate.

Rough Country recommends a certified technician installs this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read all the instructions before beginning the installation. Check the kit hardware against the kit contents. Be sure you have all the needed parts and understand where they go. Also please review the tools needed list and make sure you have needed tools. If you have any questions please call us at 800-222-7023..

NOTICE TO DEALER AND VECHICLE OWNER

If installing on a vehicle equipped with a long arm suspension only, please be advised this kit fits only the Rough Country Long Arm suspension due to the mounting points of the control arm mounting brackets. Any vehicle equipped with any Rough country product must have the "Warning to Driver" decal installed on the sun visor or dash. The decal is to act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics. **INSTALLING DEALER**—It is your responsibility to install the warning decal and to forward these installation instructions on to the vehicle owner for review and to be kept in the vehicle for its service life.

KIT CONTENTS

Skid Plate
Transmission Mount Plate
Poly Bag Containing:
- **3/8" x 1" Bolts (4)**
- **1/2" x 1 1/2 Bolts (6) For 97-02 Models**
  (03-UP Models use stock bolts)
- **1/2" Flat Washer (6)**

TOOLS NEEDED:

13mm Socket / Wrench
3/4" Socket / Wrench *OR*
18mm Socket / Wrench
9/16" Socket



TORQUE SPECS:

Size	Grade 5	Grade 8
3/8"	30 ft/lbs	35 ft/lbs
1/2"	65 ft/lbs	90 ft/lbs
9/16"	95 ft/lbs	130 ft/lbs