Rough Country 1146 Installation Instructions

Quick Disconnect Sway Bar Links for 3.5–6-Inch Lift

Part number: 1146

trailfortress.com/rough-country-quick-disconnect-sway-links-1146

Scan for fitment, price and install help

92114600A

JK / JL 4”-6” Front Quick Disconnects

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.
If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.
Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.
Periodically check all hardware for tightness.

KIT CONTENTS:

Dr Frame Bracket x1
Pass Frame Bracket x1
5/16” x 1” Self Tap Bolt x4
Link Body x2
Link End x2
Mounting Pins x2
1/2” Nut x2
1/2” Flat Washer x2
12mm Jam Nut x2
12mm Lock Nut x2
Hitch Pin x2

TOOLS NEEDED:

16mm Socket / Wrench
18mm Socket / Wrench
19mm Socket / Wrench
21mm Wrench
1/2” Socket
Small Phillips Screwdriver
17/64” Drill Bit
Drill Motor
Center punch
Cut Off Wheel
Paint Marker



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs