TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 1162 Installation Instructions

Winch Mounting Plate for Jeep Wrangler JK (2007-2017)

Part number: 1162

trailfortress.com/winch-mounting-plate-jeep-wrangler-jk-rough-country-1162

Scan for fitment, price and install help



92117300

JK WINCH / D-RING MOUNTING SYSTEM

Thank you for choosing Rough Country Off road Products

Please read instructions before beginning installation. Check the kit hardware against the parts list and product layout. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

If questions exist we will be happy to answer any questions concerning the design, function, and correct use of this product.

The installer must verify that the mounting kit does not interfere with the factory air bag sensors, which must not be relocated or modified in any way. The vehicles air bag system may not operate properly if the winch mounting kit is not mounted in compliance with the vehicle manufacturers recommendations.

Winch mounting should only be performed on vehicles with standard OEM bumpers.

Please note the tightening sequence on the last page. This sequence must be followed to ensure proper fit of winch plate and winch plate brackets.

Note: If the vehicle is equipped with factory bumper shims, these will not be reused.

Kit Contents

1– Mounting Plate
2– Front Mounting Brackets
1– Driver Side Mounting Brk
1– Pass Side Mounting Brk
1-Dr side d-ring bracket
1-Pass side d-ring bracket
2-D-rings

1- 1162Bag

4– 9/16”x1 1/2” Bolts
6– 9/16” Flat Washers
2– 9/16” Lock Washers
2– 9/16” Lock Nuts
8– 12mm-1.75 Nuts
4– 3/8” x 1 1/2” bolts
4– 3/8” Lock Washers
4– 3/8” Flat Washers

Tools Needed

Phillips screw driver
13/16” Socket
7/8” Wrench
9/16” Socket
19mm Socket
18mm Socket
15mm Socket
1/2” Drill Bit
Drill
Cutting Tool
Thread Locker

Torque Specs

Size	Grade 5	Grade 8
5/16”	15 ft/lbs	20 ft/lbs
3/8”	30 ft/lbs	35 ft/lbs
7/16”	45 ft/lbs	60 ft/lbs
1/2”	65 ft/lbs	90 ft/lbs
9/16”	95 ft/lbs	130 ft/lbs
5/8”	135 ft/lbs	175 ft/lbs
3/4”	185 ft/lbs	280 ft/lbs

INSTALLATION INSTRUCTIONS

1. Place vehicle on a flat surface and set emergency brake.
2. Using a small phillips screwdriver, remove the 2 plastic screws on top of the front bumper cover. Retain Stock hardware. **See Photo 1**.
3. Remove the 4 plastic screws holding the skid plate to the front bumper, using a small Phillips screw driver Retain stock hardware. **See Photo 2**.



Photo 1



Photo 2