Rough Country 1196 Installation Instructions

1196

Part number: 1196

trailfortress.com/rough-country-throttle-body-spacer-1196

Scan for fitment, price and install help



92119600

99-06 GM VORTEC 4.8L/5.3L/6.0L THROTTLE BODY SPACER

Thank you for choosing Rough Country.

⚠ WARNING Rough Country recommends a certified technician installs this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

⚠ WARNING Please read all the instructions before beginning the installation. Check the kit hardware against the parts list. Be sure you have all the needed parts and understand where they go. Also please review the tools needed list and make sure you have needed tools. Do not add, alter this Rough Country product. We will not be responsible for any product that is altered.

⚠ NOTICE **DEALER AND VEHICLE OWNER**

Any vehicle equipped with any Rough country product must have the ñWarning to Driverò decal installed on the sun visor or dash. **INSTALLING DEALER**ð It is your responsibility to install the warning decal and to forward these installation instructions on to the vehicle owner for review and to be kept in the vehicle for its service life.

TOOLS NEEDED:
10mm Socket
4mm Allen Wrench
5mm Allen Wrench
Flat Head Screwdriver
Vise Grips

KIT CONTENTS:
1-Throttle Body Spacer
1-Gasket
3-Cable Brackets
1-1196Bag1



Install Instructions

1. Remove the plastic vortec engine cover by loosing the bolts with a 10mm socket. **See Photo 1.**
2. Loosen the hose clamp with a screwdriver and remove from the throttle body. Also remove the rubber hose from the air cleaner assembly. **See Photo 2.**



