TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 1200 Installation Instructions

Rear Sway Bar Drop Kit for Ford Bronco 4WD (1980-1996)

Part number: 1200

trailfortress.com/rough-country-rear-sway-bar-drop-kit-1200

Scan for fitment, price and install help

921120000

ROUGH COUNTRY SUSPENSION SYSTEMS®

80-96 Ford Bronco 4-6” Lift Rear Sway Bar Brackets

Thank you for choosing Rough Country for your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page and the product layout on the last page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

If questions exist we will be happy to answer any questions concerning the design, function, and correct use of our products.

KIT CONTENTS

2-Sway Bar Drop Brkts
1-Kit Bag including
4-1/2ò x 1.5ò Bolts
4-1/2ò Nylock Nuts
8- 1/2ò Flat Washers



TOOLS NEEDED

7/8ò Deep Well Socket
18mm Socket
18mm Wrench
3/4ò Socket
3/4ò Wrench
Floor Jack
Jack Stand

INSTALLATION

1. Jack up the rear of the vehicle and support the vehicle with jack stands, so that the rear wheels are off the ground
2. Remove the rear tires/wheels. Using a 7/8ò deep well socket.
3. Using a 18mm socket, and wrench remove the factory sway bar links from the frame. Save hardware for reuse. **See Photo 1.**
4. Install the supplied sway bar drop bracket, using the supplied 1/2ò hardware from 1200bag, into the factory sway bar link hole and the slot in the frame. Tighten using a 3/4ò wrench and socket. **See Photo 2&3**.





