TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 12530 Installation Instructions

6-Inch Lift Kit with N3 Shocks for Chevy/GMC 4WD (1973-1976)

Part number: 12530

trailfortress.com/6-inch-lift-kit-chevy-gmc-4wd-rough-country-12530

Scan for fitment, price and install help