TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 13004 Installation Instructions

Mud Flap Delete Kit for Silverado 2500/3500 HD (2020–2025)

Part number: 13004

trailfortress.com/rough-country-mud-flap-delete-13004

Scan for fitment, price and install help

ROUGH COUNTRY SUSPENSION SYSTEMS®

921130040

CHEVY 2020-2024 2500 MUD FLAP DELETE

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.

Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Periodically check all hardware for tightness.

KIT CONTENTS:

Dr. Front Cap (94034010)
Pass. Front Cap (94034011)
Dr. Rear - Front Cap (94034012)
Pass. Rear - Front Cap (94034013)
Dr. Rear - Rear Cap (94034014)
Pass. Rear - Rear Cap (94034015)

Part numbers are embossed on caps for identification.

TOOLS REQUIRED:

T15 Torx
13mm Wrench or Socket
Paint Pen
Metal Cutting Saw
Sandpaper
Paint
Tape Measurer
Scissors



Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16”	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8”	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16”	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2”	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16”	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8”	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4”	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs