TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 1321 Installation Instructions

1.5-Inch Leveling Kit for Silverado 1500 Trail Boss (2019-2025)

Part number: 1321

trailfortress.com/1-5-inch-leveling-kit-silverado-1500-trail-boss-rough-country-1321

Scan for fitment, price and install help

921132100

CHEVY 2019 Trail Boss Front Leveling Kit

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

This suspension system was developed using a 295/60/20, tire with factory 20” wheels. **Note** if wider tires are used, offset wheels will be required and trimming will be required.

⚠NOTICE If equipped the electric power steering must be unplugged before any of the steering components are removed. Failure to do so may cause damage to the electric power steering.

If you have any questions concerning the design, function, and correct use of our products please contact us at 800-222-7023.

⚠NOTICE NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service life.

TOOLS NEEDED:
Spring compressor
hammer
Small pry bar
10mm socket and wrench
13mm socket
17mm socket and wrench
18mm socket
21mm socket
36mm socket

KIT CONTENTS:
Strut Preload Spacers x 2
Upper Strut Spacers x 2