Rough Country 1402 Installation Instructions

Dual Front Shock Kit for Ford F-250/F-350 Super Duty 4WD (1999-2004)

Part number: 1402

trailfortress.com/rough-country-dual-front-shock-kit-1402

Scan for fitment, price and install help