Rough Country 16230 Installation Instructions

6-Inch Lift Kit for Magnetic Ride Tahoe, Suburban & Yukon 4WD

Part number: 16230

trailfortress.com/6-inch-lift-kit-magnetic-ride-tahoe-suburban-yukon-4wd-rough-country-16230

Scan for fitment, price and install help

921162300B

ROUGH COUNTRY SUSPENSION SYSTEMS®

16230BAG3

14-19 TAHOE/YUKON/SUB 6” KIT

Thank you for choosing Rough Country for your suspension needs. We appreciate your business!!

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware. Be sure you have all needed parts and know where they go.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur. Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and correct use of our products.

This kit is packaged as a leveling kit—raising the front 6” and the rear 5”.

Due to differences in manufacturing, dimension and inflated measurements, tire and wheel combinations should be test fit prior to installation.

This kit was developed using a 35x12.50R22 on a factory 22” wheel and a 1/4” wheel spacer. Minor inner fender/air dam trimming and adjustment of the factory step is required with this combination of wheel and tire.

⚠NOTICE NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service life.

trailfortress.com/6-inch-lift-kit-magnetic-ride-tahoe-suburban-yukon-4wd-rough-country-16230