Rough Country 203 Installation Instructions

203

Part number: 203

trailfortress.com/rough-country-3-25-inch-kit-203

Scan for fitment, price and install help



07-11 GM 4WD 1500 P/U 1 1/4” Body Lift

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this kit. Attempts to install this kit without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read instructions before beginning installation. Check the kit hardware against the kit contents list page. Be sure you have all needed parts and know where they go. Review tools needed list and make sure you have the tools needed to install the kit.

PRODUCT USE INFORMATION

We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and use of our products by calling 800-222-7023.

Kit was designed for use with both standard cab and 4 door models. Standard cabs will not utilize all cab mount spacers. Standard cabs only will use the cab strap extension brackets.
This body lift was developed using a 33x12.5x20 tire with factory wheels. Combo kits are available. Ask your Rough Country Dealer for more info.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder of the vehicles unique handling characteristics. These instructions should be kept in the vehicle for its service life.

Kit Contents:

2-Fr Bumper Outer Relocation Brackets
2-Fr Bumper Frame Brackets
8-1 1/4” X 3” Cab Spacers
8-1 1/4” X 2” Bed Spacers
2-Standard Cab Strap Ext.

RC701BAG Containing:

- ***For Front Cab Mounts:***
  - **14mmx 140mm Bolts (6)**
  - **12mm x 140mm Bolts (2)**
- ***For Front Bumper Brackets:***
  - **3/8” x 1” Bolts (4)**
  - **3/8” Flat Washers (4)**
  - **3/8” Lock Nuts (4)**
- ***For Bed Mounts:***
  - **12mm x 65mm Bolt (6)**
- ***For Rear Bumper:***
  - **10MM Nut (2)**
  - **1-1/4” Tall X 2’ 9/16” ID Pucks (2)**
  - **1” Tall X 2” Body Pucks (2)**
  - **14mm x 60mm Bolts (4)**
- ***For Ground Wire Extension:***
  - **1/4” x 3/4” Bolt (1)**
  - **1/4” Flat Washer (2)**
  - **1/4” Lock Nut (1)**
- **For Strap Extension:**
  - **12mm x 35mm Bolts (2)**
  - **12mm Flange Lock (2)**
  - **1/2” Flat Washer (2)**

Tools Needed:

Jack	**8mm Socket**
Jack Stands	**10mm Socket / Wrench**
Wood Blocks (2x4)	**14mm Socket / Wrench**
Pliers	**13mm Socket / Wrench**
Hammer	**15mm Socket / Wrench**
Phillips Screwdriver	**16mm Socket / Wrench**
Drill Motor	**18mm Socket / Wrench**
1/2” Drill Bit	**19mm Socket / Wrench**
Reciprocating Saw	**21mm Socket / Wrench**
Clamp	**22mm Socket / Wrench**
	Hand Grinder



ROUGH COUNTRY SUSPENSION SYSTEMS