Rough Country 211 Installation Instructions

211

Part number: 211

trailfortress.com/rough-country-3-75-inch-lift-kit-211

Scan for fitment, price and install help



07-11 GM 1500 Pickup, Avalanche, Yukon, Tahoe, Suburban Front 2.5” Kit

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

Part # 1307 Bag fits 07-UP vehicles with fabricated & cast steel lower control arms. For models equipped with a alumi num lower control arm Part # 1308 Bag is available.

As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

This suspension system was developed using a 285/70/17, tire with factory wheels. **Note** if wider tires are used, offset wheels will be required and trimming will be required.

If you have any questions concerning the design, function, and correct use of our products please contact us at 800-222-7023.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service life.







07-11 GM 4WD 1500 P/U 1 1/4” Body Lift

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this kit. Attempts to install this kit without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read instructions before beginning installation. Check the kit hardware against the kit contents list page. Be sure you have all needed parts and know where they go. Review tools needed list and make sure you have the tools needed to install the kit.

PRODUCT USE INFORMATION

We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and use of our products by calling 800-222-7023.

Kit was designed for use with both standard cab and 4 door models. Standard cabs will not utilize all cab mount spacers. Standard cabs only will use the cab strap extension brackets.
This body lift was developed using a 33x12.5x20 tire with factory wheels. Combo kits are available. Ask your Rough Country Dealer for more info.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder of the vehicles unique handling characteristics. These instructions should be kept in the vehicle for its service life.

Kit Contents:

2-Fr Bumper Outer Relocation Brackets
2-Fr Bumper Frame Brackets
8-1 1/4” X 3” Cab Spacers
8-1 1/4” X 2” Bed Spacers
2-Standard Cab Strap Ext.

RC701BAG Containing:

- ***For Front Cab Mounts:***
  - **14mmx 140mm Bolts (6)**
  - **12mm x 140mm Bolts (2)**
- ***For Front Bumper Brackets:***
  - **3/8” x 1” Bolts (4)**
  - **3/8” Flat Washers (4)**
  - **3/8” Lock Nuts (4)**
- ***For Bed Mounts:***
  - **12mm x 65mm Bolt (6)**
- ***For Rear Bumper:***
  - **10MM Nut (2)**
  - **1-1/4” Tall X 2’ 9/16” ID Pucks (2)**
  - **1” Tall X 2” Body Pucks (2)**
  - **14mm x 60mm Bolts (4)**
- ***For Ground Wire Extension:***
  - **1/4” x 3/4” Bolt (1)**
  - **1/4” Flat Washer (2)**
  - **1/4” Lock Nut (1)**
- **For Strap Extension:**
  - **12mm x 35mm Bolts (2)**
  - **12mm Flange Lock (2)**
  - **1/2” Flat Washer (2)**

Tools Needed:

Jack	**8mm Socket**
Jack Stands	**10mm Socket / Wrench**
Wood Blocks (2x4)	**14mm Socket / Wrench**
Pliers	**13mm Socket / Wrench**
Hammer	**15mm Socket / Wrench**
Phillips Screwdriver	**16mm Socket / Wrench**
Drill Motor	**18mm Socket / Wrench**
1/2” Drill Bit	**19mm Socket / Wrench**
Reciprocating Saw	**21mm Socket / Wrench**
Clamp	**22mm Socket / Wrench**
	Hand Grinder



ROUGH COUNTRY SUSPENSION SYSTEMS