Rough Country 213 Installation Instructions

3.25-Inch Lift Kit for 2014–2015 Chevy/GMC 1500 2WD/4WD

Part number: 213

trailfortress.com/rough-country-3-25-inch-kit-213

Scan for fitment, price and install help



92130400

2014 GM 1500 Pickup Front Leveling Kit

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is, the easier it will roll. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

This suspension system was developed using a 285/70/17, tire with factory wheels. **Note** if wider tires are used, offset wheels will be required and trimming will be required.

****Note**** The electric power steering must be unplugged before any of the steering components are removed. Failure to do so may cause damage to the electric power steering.

If you have any questions concerning the design, function, and correct use of our products please contact us at 800-222-7023.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service life.

Tools Needed:
18mm Wrench
15mm Socket
15mm Wrench
17mm Wrench
21mm Wrench
7/32 Allen Wrench
Flat Screwdriver
Hammer





2014 GM 4WD 1500 P/U 1 1/4" Body Lift

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this kit. Attempts to install this kit without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read instructions before beginning installation. Check the kit hardware against the kit contents list page. Be sure you have all needed parts and know where they go. Review tools needed list and make sure you have the tools needed to install the kit.

PRODUCT USE INFORMATION

We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and use of our products by calling 800-222-7023.

Kit was designed for use with both standard cab and 4 door models. Standard cabs will not utilize all cab mount spacers. Standard cabs only will use the cab strap extension brackets.

This body lift was developed using a 33x12.5x20 tire with factory wheels. Combo kits are available. Ask your Rough Country Dealer for more info.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a ñWarning to Driverò decal installed on the inside of the windshield or on the vehicleôs dash. The decal should act as a constant reminder of the vehicles unique handling characteristics. These instructions should be kept in the vehicle for its service life.

Kit Contents:

1-Fr Bumper Driver Relocation Bracket
1-Fr Bumper Passenger Relocation Bracket
1-E-brake Bracket
1-Rear Bumper Shim
1-Rr Bumper Driver Relocation Bracket
1-Rr Bumper Passenger Relocation Bracket
6-1 1/4" 2014 GM Cab Spacers
2-1 1/4" X 3" Body Pucks
10-1 1/4" X 2" Body Pucks
2-Standard Cab Strap Ext.

RC714BAG2 Containing:

- **12—3/8" x 2.25" Bolt**
- **12—3/8" Washers**
- **12—3/8" Nylocks**
- **1—1/2" x 1" Bolt**
- **3—1/2" Washers**
- **1—1/2" Nylock**
- **2—10mm x 30mm Button Head Bolts**
- **2—3/8" USS Washers**
- **4—12mm Flange Lock**
- **2—12mm x 35mm Bolt**

RC714BAG3 Containing:

- **8—12mm x 65mm Bolts**
- **8—1/2" Washers**
- **2—14mm x 140mm Bolts**

Tools Needed:

Jack
Jack Stands
Wood Blocks (2x4)
Pliers
Hammer
Phillips Screwdriver
Drill Motor
1/2" Drill Bit
Reciprocating Saw

8mm Socket
10mm Socket / Wrench
11mm Socket / Wrench
12mm Socket / Wrench
13mm Socket / Wrench
14mm Socket / Wrench
15mm Socket / Wrench
16mm Socket / Wrench
18mm Socket / Wrench
19mm Socket / Wrench
21mm Socket / Wrench
22mm Socket / Wrench
Hand Grinder
#15, #40, & #45 Torx bit