TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

# Rough Country 23530 Installation Instructions

2-Inch Lift Kit with N3 Shocks for Chevy/GMC C10/K10 and K5 Blazer 4WD

Part number: 23530

trailfortress.com/rough-country-2-inch-lift-kit-23530

Scan for fitment, price and install help