Rough Country 23970 Installation Instructions

23970

Part number: 23970

trailfortress.com/rough-country-4-5-inch-lift-kit-23970

Scan for fitment, price and install help

92123900A

ROUGH COUNTRY SUSPENSION SYSTEMS®

123930BAG

99-06 2WD CHEVY/GM 1500 4.5” LIFT

Thank you for choosing Rough Country for all of your suspension needs.
Rough Country recommends that a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read all the instructions before beginning the installation. Check the kit hardware against the ‘‘Kit Contents’’ list below. Be sure you have all the needed parts and understand where they go. Also, please review the “Tools Needed” list to be certain you have the necessary tools to complete the installation.

PRODUCT USE INFORMATION

⚠WARNING As a general rule, the taller a vehicle is the easier it will roll. We strongly recommend that seat belts and shoulder harnesses be worn at all times. Braking performance and capabilities are decreased when significantly larger/ heavier tires and wheels are used. Do not add, alter, or fabricate any factory or after-market parts which increase vehicle height over the intended height of the Rough Country product purchased. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

Due to differences in manufacturing, dimension and inflated measurements, tire and wheel combinations should be test fit prior to installation. **This kit was developed using a 33.12.0-16 on stock wheel.**

⚠NOTICE **NOTICE TO DEALER AND VEHICLE OWNER**

Any vehicle equipped with any Rough country product must have the **“Warning to Driver”** decal installed on the sun visor or dash. The decal is to act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics. INSTALLING DEALER—It is your responsibility to install the warning decal and to forward these installation instructions on too the vehicle owner for review and to be kept in the vehicle for its service life.

Kit Contents:

7501:
1-Dr Side Knuckle (1)
1-Pass Side Knuckle (1)

9258:
COIL SPRING (2)

1239BOX1:
Fr Shock-660766 (2)
Rr Shock-660739 (2)
Shock Bag (1232 BAG2) (2)
Rear Fabbed Block(2)
Rear U-bolts (4)
9/16” Bag (1)



Bag Contents:

1232Bag2:
STEM CUSHION (4)
RETAINER (4)
3/8 NUT (2)

9/16 BAG:
9/16 NYLOCK (8)
9/16 WASHER (8)

Tools Needed:
18mm Wrench/Socket
15mm Wrench/Socket
13mm Wrench/Socket
24mm Wrench/Socket
9/16” Wrench/Socket
10mm Wrench/Socket
7/8” Wrench/Socket
21mm Wrench/Socket
Jack and stands
Wheel Chocks
WD40 / Lubricant

trailfortress.com/rough-country-4-5-inch-lift-kit-23970