TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 27030 Installation Instructions

2-Inch Lift Kit with N3 Shocks for Chevy Tahoe Z71 (2000–2006)

Part number: 27030

trailfortress.com/rough-country-2-inch-lift-kit-27030

Scan for fitment, price and install help