TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

Rough Country 27330 Installation Instructions

2-Inch Lift Kit with N3 Shocks for Tahoe & Yukon (2000–2006)

Part number: 27330

trailfortress.com/rough-country-2-inch-lift-kit-27330

Scan for fitment, price and install help