TRAIL FORTRESS

BUILT FOR THE TRAIL. CHECKED FOR YOUR TRUCK.

# Rough Country 28300 Installation Instructions

1.5-2 Inch Torsion Key Lift Kit for Silverado and Sierra 1500

Part number: 28300

trailfortress.com/1-5-2-inch-torsion-key-lift-kit-silverado-and-sierra-1500-rough-country-28300

Scan for fitment, price and install help

921283000

ROUGH COUNTRY SUSPENSION SYSTEMS®

28300BAG

# 99-06 CHEVY/GM 1500 1.5-2” Kit

**Thank you for choosing Rough Country for your suspension needs.**

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

**Please read instructions before beginning installation.**

## PRODUCT USE INFORMATION

**⚠WARNING** As a general rule, the taller a vehicle is, the easier it will roll. Offset, as much as possible, what is lost in rollover resistance by increasing tire track width. In other words, go "wide" as you go "tall".

Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands, lifts, and/or combining body lift with suspension lifts voids all warranties. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

Braking performance and capability are decreased when significantly larger/heavier tires and wheels are used. Take this into consideration while driving.

The required installation time for this system is approximately 2.5 hours. This suspension system was developed using **285x75R16 tire on an 8” wheel**. Before installing other combinations, please consult your local tire and wheel specialist. If questions exist on the design, function, and correct use of our products please contact us at 800-222-7023.

**⚠NOTICE** **NOTICE TO DEALER AND VEHICLE OWNER**

Any vehicle equipped with any Rough Country product should have a “Warning to Driver” decal installed on the inside of the windshield or on the vehicle’s dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service.

**⚠NOTICE** Note to installer : Before installation begins we recommend that a test drive be performed. While driving check for uncommon sounds and/or vibrations . What you feel and hear during the test drive will only magnify once lift kit is installed. Advise you to discuss possible issues identified from drive with customer before proceeding to install this kit.

**Tools Needed:**

15mm Wrench /socket
21mm Wrench/Socket
3/4” Wrench/Socket
13/16” Wrench/Socket
Drill Motor
17/32” Drill
Torque Wrench

Rough Country Torsion Tool **1067**

**Kit Contents:**

**28300 Box Contains:**

(2)Torsion Keys
(2) Rear Shock Brackets
(2) Rear Lift Blocks
(4) U-Bolts
(1) 9/16BAG
(1) 28300BAG2

**28300BAG2 Contains:**

(2) Upper Frt Shock Spacers
(2) 1/2” x 1.5” Bolts
(2) 1/2” Nuts
(4) 1/2” Flat Washers
(2) 1/2” Lock Washers
(2) 9/16” x 3” Bolts
(2) 9/16” Flat Washers
(2) 9/16” Top Lock Nuts
(2) Shock Brkt Sleeves